

MATERIAL LIST

- (24) treated 8-ft 2x4's
- (5) treated 8-ft 5.5" wide deck boards
- (6-11) yds of camo material or two camo tarps
- 1 pound 3" deck screws
- 2 pounds 10d galvanized common nails
- 2 pounds 16d galvanized common nails
- 1 pound #12 galvanized decking finish nails
- (1) piece of 8ft long by 3ft metal roofing (Shown Below)



You will cut the 8-ft piece in two equal halves

- (20) screws for fastening roofing
- (42) 3-inch long 3/8" diam galvanized lag screws & washers
- (1) 5-inch long 3/8" diam galvanized lag screw & washer
- (1) 12-ft treated 2x4, cut in half
- (1) 10-ft long piece of concrete reinforcing rod (optional)

CUTTING INSTRUCTIONS

- (12) 8-ft 2x4's Trimmed to 96" (if needed)
- (2) 6-ft 2x4's from 12-ft piece (have supplier cut this)
- (11) 47 15/16" pieces of treated 2x4 (exact!)
- (3) 47 15/16" pieces of 2x4 ripped to 2 1/4" wide (Exact!)
- (2) 44 15/16" pieces of 2x4 ripped to 2 1/4" wide (Exact!)
- (4) 19 1/2" pieces of 2x4
- (2) 67 1/2" pieces of 2x4
- (8) 23 7/8" pieces of 2x4
- (2) 48" long pieces of metal roofing
- (7) 47 15/16" long pieces of 5.5" wide decking
- (2) 38 1/8" long pieces of 5.5" wide decking
- (1) 2x4 scrap about 12 inches long
- (4) 2 1/2 ft-long pieces of reinforcing rod (optional)